




## "Observer 100" Series Pedestal Alarm

## Features & Benefits




\*Note: Consult the factory for other available options.



**ALARM SYSTEMS** 

## "Observer 100" Series Pedestal Alarm

## **Wiring Diagram**



NOTES: Two separate power supplies are recommended – one for the alarm circuit and one for the pump circuit. On the 120VAC outlet – wires connect screw terminals. If using ring or fork terminals, size them to appropriately fit #8-32 threaded screws. When using Auxiliary contacts, contact load must not exceed 3 amps. Add a cord grip appropriate to seal the conductors at your point of entry into the enclosure. "COM" connects to voltage. "NO" should be connected to devices that must operate while in an alarm state (IE: a remote mounted alarm light. Most applications will require the "normally open" contact.) Other devices may require inverted logic and should connect to "NC."